



Current Location



PlacemarkView/Presenter







```
class PlacemarkPresenter(view: BaseView) : BasePresenter(view) {
 var map: GoogleMap? = null
 var placemark = PlacemarkModel()
 var <u>defaultLocation</u> = Location( lat: 52.245696, lng: -7.139102, zoom: 15f)
 var edit = false;
 init {...}
 fun doConfigureMap(m: GoogleMap) {...}
 fun locationUpdate(lat: Double, lng: Double) {...}
 fun doAddOrSave(title: String, description: String) {...}
 fun doCancel() {...}
 fun doDelete() {...}
 fun doSelectImage() {...}
 fun doSetLocation() {...}
 override fun doActivityResult(requestCode: Int, resultCode: Int, data: Intent) {...}
```

```
class PlacemarkView : BaseView(), AnkoLogger {
  lateinit var presenter: PlacemarkPresenter
  var placemark = PlacemarkModel()
 override fun onCreate(savedInstanceState: Bundle?) {...}
 override fun showPlacemark(placemark: PlacemarkModel) {....}
 override fun onCreateOptionsMenu(menu: Menu): Boolean {...}
 override fun onOptionsItemSelected(item: MenuItem?): Boolean {...}
 override fun onActivityResult(requestCode: Int, resultCode: Int, data: Intent?) {...}
 override fun onBackPressed() {...}
 override fun onDestroy() {...}
 override fun onLowMemory() {...}
 override fun onPause() {...}
 override fun onResume() {...}
  override fun onSaveInstanceState(outState: Bundle?) {...}
```


```
class PlacemarkPresenter(view: BaseView) : BasePresenter(view) {
 var map: GoogleMap? = null
 var placemark = PlacemarkModel()
 var defaultLocation = Location(52.245696, -7.139102, 15f)
 var edit = false;
                                                                                  init(toolbarAdd)
 init {
   if (view.intent.hasExtra("placemark_edit")) {
      edit = true
      placemark = view.intent.extras.getParcelable<PlacemarkModel>("placemark_
                                                                                  mapView.getMapAsync {
     view.showPlacemark(placemark)
   } else {
      placemark.lat = defaultLocation.lat
      placemark.lng = defaultLocation.lng
  fun doConfigureMap(m: GoogleMap) {
   map = m
    locationUpdate(placemark.lat, placemark.lng)
 fun locationUpdate(lat: Double, lng: Double) {
    placemark.lat = lat
    placemark.lng = lng
    placemark.zoom = 15f
   map?.clear()
   map?.uiSettings?.setZoomControlsEnabled(true)
    val options = MarkerOptions().title(placemark.title).position(LatLng(placemark.lat, placemark.lng))
    map?.addMarker(options)
   map?.moveCamera(CameraUpdateFactory.newLatLngZoom(LatLng(placemark.lat, placemark.lng), placemark.zoom))
    view?.showPlacemark(placemark)
```

```
class PlacemarkView : BaseView(), AnkoLogger {
  lateinit var presenter: PlacemarkPresenter
  var placemark = PlacemarkModel()
  override fun onCreate(savedInstanceState: Bundle?) {
   super.onCreate(savedInstanceState)
   setContentView(R.layout.activity_placemark)
   presenter = initPresenter (PlacemarkPresenter(this)) as PlacemarkPresenter
   mapView.onCreate(savedInstanceState);
     presenter.doConfigureMap(it)
   chooseImage.setOnClickListener { presenter.doSelectImage() }
   placemarkLocation.setOnClickListener { presenter.doSetLocation() }
```

build.gradle

implementation 'com.google.android.gms:play-services-location:17.0.0'

play-service-location Library




Location Permissions


If an app is to use the users location, there are 2 permission steps required

1: AndroidManifest.xml

2: Dialog Directly with the user



2: Dialog Directly with the user



New Helper functions to support this interaction:


```
fun checkLocationPermissions(activity: Activity): Boolean {...}

fun isPermissionGranted(code: Int, grantResults: IntArray): Boolean {...}
```

<u>LocationHelper</u>

PlacemarkPresenter - Acquire Permissions

```
class PlacemarkPresenter(view: BaseView) : BasePresenter(view) {
  • • •
 init {
   if (view.intent.hasExtra("placemark_edit")) {
      edit = true
      placemark = view.intent.extras.getParcelable<PlacemarkModel>("placemark_edit")
     view.showPlacemark(placemark)
   } else {
     if (checkLocationPermissions(view)) {
       // get current location
 override fun doRequestPermissionsResult(requestCode: Int, permissions: Array<String>,
                                          grantResults: IntArray) {
   if (isPermissionGranted(requestCode, grantResults)) {
     // get current Location
   } else {
      locationUpdate(defaultLocation.lat, defaultLocation.lng)
```



PlacemarkPresenter - Acquire Permissions

```
class PlacemarkPresenter(view: BaseView) : BasePresenter(view) {
  . . .
 init {
   if (view.intent.hasExtra("placemark_edit")) {
     edit = true
     placemark = view.intent.extras.getParcelable<PlacemarkModel>("placemark_edit")
                                                                                             Allow Placemark to
     view.showPlacemark(placemark)
                                                                                             access this device's
   } else {
     if (checkLocationPermissions(view)) {
                                                                                             location?
       // get current location
                                                                                                          DENY
                                                                                                                   ALLOW
 override fun doRequestPermissionsResult(requestCode: Int, permissions: Array<String>,
                                        grantResults: IntArray) {
   if (isPermissionGranted(requestCode, grantResults)) {
     // get current Location
   } else {
     locationUpdate(defaultLocation.lat, defaultLocation.lng)
```

PlacemarkPresenter - Acquire Permissions

```
class PlacemarkPresenter(view: BaseView) : BasePresenter(view) {
  • • •
 init {
   if (view.intent.hasExtra("placemark_edit")) {
      edit = true
      placemark = view.intent.extras.getParcelable<PlacemarkModel>("placemark_edit")
     view.showPlacemark(placemark)
   } else {
      if (checkLocationPermissions(view)) {
        // get current location
 override fun doRequestPermissionsResult(requestCode: Int, permissions: Array<String>,
                                          grantResults: IntArray) {
   if (isPermissionGranted(requestCode, grantResults)) {
     // get current Location
   } else {
      locationUpdate(defaultLocation.lat, defaultLocation.lng)
```



Allow **Placemark** to access this device's location?

DENY ALLOW

Acquire current Location (permissions previously granted)

Acquire current Location (permissions granted just now)

Permission Denied, show default location

Fused Location Client


Acquire a reference to the Fused location provider




```
class PlacemarkPresenter(view: BaseView) : BasePresenter(view) {
    var locationService: FusedLocationProviderClient = LocationServices.getFusedLocationProviderClient(view)
```

. . .

```
@SuppressLint("MissingPermission")
fun doSetCurrentLocation() {
   locationService.lastLocation.addOnSuccessListener {
     locationUpdate(Location(it.latitude, it.longitude))
   }
}
```



New method to request current location



```
class PlacemarkPresenter(view: BaseView) : BasePresenter(view) {
 var map: GoogleMap? = null
 var placemark = PlacemarkModel()
 var defaultLocation = Location(52.245696, -7.139102, 15f)
 var edit = false;
 var locationService: FusedLocationProviderClient = LocationServices.getFusedLocationProviderClient(view)
 init {
   if (view.intent.hasExtra("placemark_edit")) {
     edit = true
     placemark = view.intent.extras.getParcelable<PlacemarkModel>("placemark_edit")
     view.showPlacemark(placemark)
   } else {
     if (checkLocationPermissions(view)) {
        doSetCurrentLocation()
 @SuppressLint("MissingPermission")
 fun doSetCurrentLocation() {
   locationService.lastLocation.addOnSuccessListener {
     locationUpdate(it.latitude, it.longitude)
 override fun doRequestPermissionsResult(requestCode: Int, permissions: Array<String>, grantResults: IntArray) {
   if (isPermissionGranted(requestCode, grantResults)) {
     doSetCurrentLocation()
   } else {
     locationUpdate(defaultLocation.lat, defaultLocation.lng)
 fun locationUpdate(lat: Double, lng: Double) {
   placemark.lat = lat
   placemark.lng = lng
   placemark.zoom = 15f
   map?.clear()
   map?.uiSettings?.setZoomControlsEnabled(true)
   val options = MarkerOptions().title(placemark.title).position(LatLng(placemark.lat, placemark.lng))
   map?.addMarker(options)
   map?.moveCamera(CameraUpdateFactory.newLatLngZoom(LatLng(placemark.lat, placemark.lng), placemark.zoom))
   view?.showPlacemark(placemark)
```


Recover last known location


```
Suppress Permissions warnings from compiler
```

Asynchronous request to location service

Location passed as default parameter **it** to callback

Recover lat/Ing from it
Update map accordingly





For 'lastLocation' there is a noticeable lag - up to several minutes - for the location changes to percolate into the simulator